

# Installation Instructions

**Important: Please read these instructions before starting work.**

1. Check that there are no buried pipes or cables before drilling and holes. Take extreme care when using electrical equipment near water.
2. Do not fix accessories onto newly painted surfaces as chemical reactions could cause discoloration to the products. (Please refer to the manufactures instructions.)
3. We recommend the use of a masonry drill bit when fixing accessory to tiled area.

## **Supplied Mounting hardware:**

Hex key, screws and wall plugs.

## **Mounting Instructions:**

1. Establish position for accessories, making sure there is sufficient room.
2. Using a suitable cross head screw driver, Loosen the set screw in the upright post and remove the backplate. Remove the backplate cover to expose the mounting holes.
3. Hold the backplate in the required position, mark through with a pencil. If two backplates are necessary, measure the distance between the two post centers, ensuring the marks are horizontal by use of a carpenter's level.
4. Drill holes to a depth of 1" inch using a ¼" inch masonry drill and insert the wall plugs so they are flush with the wall. (NOTE: The wall plugs provided are suitable for solid walls only. If using on plasterboard or hollow walls special fittings are required. These can be obtained from a DIY outlet.)
5. Fix the backplate to the wall with the threaded hole for the set screw facing straight vertical. Replace the backplate cover, then the post, making sure that the set screw points directly downward before tightening.

## **Care Instructions:**

We recommend regular cleaning with a mild soap and dried with a soft cloth. The use of abrasive cleaners or bleaches will damage the finish.