


## Assembly Instruction Sheet #IS-LND1616MC\_R1 For Style LND1616MC

Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection. Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (3) A19 Medium Base Bulbs 100W Maximum Estimated Assembly Time: 30-45 minutes Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.  $\Delta$  Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Package Contents (Step 2 Continued) Assembly (A) by unscrewing the preassembled hex nut and lock =0 washer and then screwing the mounting screws in or out of the C Diffuser crossbar until the correct length is achieved. Once the ceiling 0 canopy and Fixture Body (B) is secure, remove the mounting ball x 1 and Fixture Body (B)) and proceed to Step 3. Hex Nut and Ceiling Α Lock Washer Canopy Crossbar Assembly Rubber Center Mounting x 1 Washer D Stem Screw x 1 x 1 Flat Mounting Washer Ball x 1 Hex Finial Н G Nut x 1 x 1 Fixture Body В x 1 Figure 2 STEP 1- Install Crossbar Assembly **STEP 3 - Wire Connections** A. Pass the supply wires through the Crossbar Assembly (A). Attach the Crossbar Assembly (A) to the Outlet Box with the head of the A. Wrap bare or green ground wire around green ground screw on the Green Ground Screw facing you. Secure it with Outlet Box Screws crossbar, no less than 2 inches from the end of the wire. Tighten the (not included). Tighten until snug. green ground screw. B. Use standard wire connectors (not included) to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into the Outlet Box. Outlet Box Figure 1 White wire White wire from outlet box from fixture Supply Wires with **Outlet Box Screws** Black wire (not included) Ground Wire Black wire from from fixture outlet box (or Red) Bare, or Green STEP 2 - Test Fit the Ceiling Canopy to the Crossbar Assembly Ground wire Ground wire from Fixture from outlet box A. Remove the mounting balls from the Crossbar Assembly (A). Place the ceiling canopy and Fixture Body (B) onto the Crossbar Assembly Green Ground Screw (A) and secure with mounting balls. Note: The ceiling canopy should be snug against the ceiling and held tight with the mounting balls. If it on the Crossbar is not, adjust the length of the mounting screws on the Crossbar Figure 3 Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184 or visit us on-line at www.quoizel.com Revised Date: 2017-11-03 © 2017 Quoizel Inc.



2of2