

Installation Guide For Style PCSH1941BCH

Tools Required

Light Source

LED

Fixture Height Adjustable 10" to 100"


⚠ Warnings and Cautions

Turn off the electricity at the circuit breaker before installation. Consult a licensed electrician if in doubt about installation.

Package Contents

Preparation: Identify and inspect all parts before beginning the installation.

Missing or damaged parts? Contact your original place of purchase.








Table of Contents



Inner Backplate Assembly



Lanyard

STEP 3

Wiring

STEP 4

Fixture Body

Glasses

STEP 6

©2019 QuoizelInc.

visit us on-line at www.quoizel.com

Released Date: 2019-09-29

