
















ZUO®


ITEM NAME/NOM D'ITEM: ROCKY SOFA

ITEM # /NO.ITEM: 100531/100532/100533

PARTS LIST / LISTE DES PIÈCES

100531A/100532A/100533A (Seat)			100540BU (Arm & Hardware)	
1	2	3	4	5
				<p>A.  X2 M8X60MM</p> <p>B.  X6 M8X17MM</p> <p>C.  X1 M5</p> <p>D.  X2 M8X18MM</p> <p>E.  X2 M10X40MM</p> <p>F.  X6</p>
X1	X1	X1	X2	<p>G.  X4 M8X80MM</p> <p>H.  X3 M4X50MM</p> <p>I.  X4</p> <p>J.  X2</p> <p>K.  X4 M4X20MM</p>

ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE



For missing parts or damaged parts, please call

USA

1-866-798-6663

Canada

514-382-6661

AI-4-171115